

SAE-EXTxx Enclosure Depth Extender

SUTTLE

Suttle's SOHO Access Enclosures may be equipped with a depth extender to provide additional room and ventilation for active equipment. Available for 28" & 42" enclosures, the depth extender adds 2" to the enclosures standard 3.75" depth. Airflow through the vented sides of the depth extender provides additional protection for temperature sensitive modules and equipment.

Go to <http://www.suttlesoho.com> to see our full line of SOHO Access Modules (SAM) and accessories.

PACKAGE CONTENTS

- 1: Enclosure Depth Extender
- 4: #6-32 screws 1" long (mounting screws)

ENCLOSURE PREPARATION

Refer to the Owner's Manual supplied with the SOHO Access Enclosure for enclosure installation instructions.

NOTE: The Enclosure Depth Extender should not be mounted until the enclosure is correctly mounted, wired, and all modules are installed.

INSTALLATION

- Thread two mounting screws into the threaded holes in the top of the enclosure. Leave screws protruding from the enclosure approximately $\frac{3}{4}$ ".
- Hang the depth extender on top two screws and secure the extender by installing the remaining screws in the bottom (Figure 1).
- Fully tighten top two screws.

